



**Thank you for your purchase of a
Graphic Express paint stencil.**

PAINT STENCIL INSTRUCTIONS



DRY APPLICATION



- #1. Do not use water or wetting solution to apply the stencil.
- #2. Place stencil on vehicle without removing backing to get correct placement. Measure carefully to get stencil in exact position.
- #3. Using masking tape, apply tape at edges of stencil butting the stencil but not overlapping stencil. This will make a guide to lay the stencil next to. Do this on as many sides as possible.
- #4. Peel apart and place the stencil on vehicle. Completely squeegee stencil making good bond to vehicle.
- #5. Do not bake the stencil. Air dry only. Remove stencil soon after paint dries.

© COPYRIGHT GRAPHIC EXPRESS 2007