

**Thank you for your purchase of a
Graphic Express window decal.**

WINDSHIELD / GLASS DECAL INSTALLATION

WET APPLICATION



#1. Use Naphtha cleaner to wash area where decal is to be installed. Clean multiple times. If any wax or silicone is left behind the decal will not stick or peel later.



#2 Measure for correct placement and alignment.



#3 Install tape guide to assure proper placement. Tape down into position.



#4 Mark decal and tape guide for placement.



#5 Make wetting solution.
1 tablespoonful of "DAWN ORIGINAL" dish liquid in one gallon of water. No Guessing.

#6 Place decal face down on a clean flat surface. Slowly peel backing liner off making sure the decal sticks to the front application tape - this will expose the decals adhesive. Apply wetting solution.



#7 Squeegee completely into position. Use light pressure at first and then re-squeegee a few times with increasing pressure.



#8 After decal is completely applied wet the top application paper tape with wetting solution and squeegee one more time. Now slowly remove the top application tape starting at one side. If the decal lifts off vehicle STOP and re-squeegee.

SOME DECALS TAKE UP TO 30 MINUTES TO STICK.



#9 Carefully clean installation area. Allow a few days for complete adhesion. The hot sun will help to remove wrinkles and bubbles.



#10 Always re-squeegee decal after spraying decal with wetting solution. This will lubricate the squeegee and decal preventing damage.