



2005-2007 MUSTANG C-STRIFE

Dear Customer, this sheet is additional instructions and helpful information for the 2005-2007 Mustang C-Stripe #K130 ONLY. Please read all instructions on the yellow application instruction sheet also supplied with this kit.



◀ On top door stripe trim excess top application tape from door handle area as shown. This will give clearance from protruding door handle when stripe is applied.



◀ Install top door stripe first to get correct spacing above body line. Align the stripe around the door handle first. This will give you the correct spacing to body seam.

▶ Connect top of 'C' section to top door stripe. Make sure you keep an even space from the body line all the way around to the bottom of door.



◀ Connect bottom door stripe making sure space to body line is even all the way to wheel well. Be sure to trim between front door seams, a sharp razor blade works best. All stripes are designed to wrap into seams to give a finished look.

DECAL KIT: #K130

